
VARIABLE RATIO DIE LUBE MIXER INSTRUCTION MANUAL



SHAMROCK AUTOMATION, INC.

320 Industrial Park Road Harrison, Arkansas 72601 Phone: (800)458-5702

Fax: (870)741-9656

TABLE OF CONTENTS

Hook up Procedure for Die Lube Mixer	Page 3
Troubleshooting the Variable Ratio Die Lube Mixer	Page 4
Servicing the Variable Ratio Die Lube Mixer	Page 5
Die Lube Mixer Repair Kit Listing	Page 6
Die Lube Mixer Drawing with Part Numbers	Page 7
Water Cylinder Valve Assembly Drawing	Page 8
Water Cylinder Assembly Drawing with Part Numbers	Page 9
Lube Cylinder Assembly Drawing with Part Numbers	Page 10
Valve Cage Assembly for the Variable Die Lube Mixer Instructions	Page 11
Valve Spool Assembly-Valve Cage Sequence Drawing with Part Numbers	Page 12
Valve Positioner Housing Drawing with Part Numbers	Page 13
Warranty	Page 14

HOOK UP PROCEDURE

No air or electrical connections are required. This mixer uses only the supply water pressure as a power source. Position mixer on edge with lube cylinder (small cylinder) at the bottom. In this position, any air trapped in the lube cylinder is automatically purged during normal operation.

WATER IN:

Connect this port to the water supply by means of a shut-off valve and a flexible hose at least three feet long to cushion water pressure surges. A minimum of 25 psi supply water pressure is recommended which produces up to 150 gallons of mixture per hour. At 40 psi up to 200 gph may be mixed. Breakaway friction in seals is high at start-up requiring higher than normal water pressure. To reduce this for a long period shut-down, shut off water supply when water cylinder rod is positioned in mid-stroke (between valve shifts).

WATER OUT:

Connect this port to a float valve in the mixture holding tank. When the mixture level lowers, this valve opens creating a pressure drop in the mixer. The mixer automatically starts pumping at a rate proportional to this pressure drop. Use copper tubing or pipe for this connection,

LUBE IN:

Although this mixer will siphon, it is recommended that the lube supply barrel be positioned above the mixer to provide a gravity feed. A shut-off valve should be placed in this line. If hose is used, be sure there are no kinks.

LUBE OUT:

The lube outlet has been separated from the water outlet for two reasons: (1) it allows the lube pumping system to operate under very low pressure which increases pumping speed and reduces wear on pump components. (2) It simplifies the testing procedure to determine the actual water-to-lube ratio. The lube outlet should be connected by means of a hose to a separate inlet into the mixture holding tank. Position this inlet so the lube pours into the water stream coming from the float valve. This assures complete mixing. Use hose or pipe for this line. If the mixture holding tank is pressurized, lube cylinder back pressure can be reduced by connecting the drain hole to the tank. This reduces the pressure drop across the mixer required for its operation.

TROUBLE SHOOTING THE VARIABLE RATIO DIE LUBE MIXER

MIXER STOPS: Check water supply pressure and float valve action. Remove valve shift rod cover, and pull or push shift rod to start mixer. Observe rod action near end of cylinder rod stroke and determine which of the three following conditions exist.

- (1) Shifter bracket moves floating spring retainer against end cap but valve does not shift. Cause: Water pressure is too low to shift valve. See note under <u>WATER IN</u>. Or water cylinder stroke reduced by sediment build-up. Loosen shifter bracket attachment screw, check for cylinder motion when shift rod is moved toward shifter bracket.
- Valve shifts before floating spring retainer touches end cap. Cause: Weak valve positioner springs, or excessive friction between floating spring retainers and shift rod. Grease spring retainers, then replace positioner springs.
- (3) Floating spring retainer contacts end cap, and valve shifts only part way. Cause: Excessive friction in positioner or floating spring retainer, a broken valve shift spring, or a worn positioner spool. Grease positioner housing with marine water resistant grease, and check shift springs.

WATER - TO - LUBE RATIO CHANGES: Check lube supply and pivot bracket setting. Then perform the following test:

- (1) **LUBE INLET RATIO CHANGES:** Remove connection at <u>LUBE IN</u> port and check flow from lube supply barrel. Check for restricted air vent in barrel.
- (2) VALVE SEAL LEAK IN LUBE CIRCUIT: Cover lube discharge pipe in holding tank with thumb and cycle mixer very slowly. Lube should force its way around thumb when lube cylinder extends. If lube flow can be held back, lube valve seals are leaking.
- (3) LUBE PISTON LEAK: Lube flowing from lube cylinder rear drain hole indicates a leaky piston seal. (A Lube Piston Seal Kit is available from Shamrock Automation)

NOTE: A lean mixture can be caused by leaking seals in the control valve or a leaking water piston. The following tests will isolate the problem:

- (a) WATER LEAK INTO LUBE SYSTEM: Shut off lube supply at lube barrel and cycle mixer slowly. Discharge from <u>LUBE OUT</u> should eventually stop. If it continues and becomes thinner, a leaky control valve seal is the cause.
- (b) LEAK ACROSS WATER CYLINDER: Turn down water supply shut-off valve until shift actuator bracket barely moves. If bracket moves against floating spring retainer but does not shift valve and water trickles out of float valve, leakage is indicated. Replace valve seals and repeat this test. If leakage continues, water piston seal needs replacing. (Water Piston Seal Kit is available from Shamrock Automation)

REPLACEMENT PARTS

All parts including the repair kits listed above may be ordered from the manufacturer using the part numbers listed at the following address:

SHAMROCK AUTOMATION, INC.

320 INDUSTRIAL PARK ROAD HARRISON, AR 72601 PHONE: (870) 741-3641 FAX: (870) 741-9656

NOTE: The mixer may be returned to the factory for repairs. All worn parts will be replaced and tested.

SERVICING THE VARIABLE RATIO DIE LUBE MIXER

CAUTION: THE WATER SUPPLY VALVE MUST BE TURNED OFF

CHANGING MIXTURE RATIO: The rocker arm connecting the two cylinder rods is marked with different water-to-lube ratios. By loosening the two screws indicated, the pivot bracket may be moved by gentle tapping. When the proper ratio number is aligned with the arrow on the pivot bracket, the two screws should be retightened.

VALVE SHIFT SPRING REPLACEMENT: Back out the set screw in the end cap, and unscrew the end cap. Remove the two screws in the shifter bracket and take off this bracket. The end cap, one shift spring and floating spring retainer will come with it, allowing the inner floating spring retainer and spring to be removed. Grease the shift rod and floating spring retainer when reassembling.

VALVE SEAL REPLACEMENT: Refer to attached sheet showing valve cage assembly.

VALVE POSITIONER SPRINGS REPLACEMENT: Remove the 1/2 x 1/2 x 2 spring retainer blocks on each side of the positioner housing, exposing the two positioner springs. (A Valve Spring Repair Kit containing positioner and shift springs is available from Shamrock Automation)

VALVE POSITIONER BEARINGS REPLACEMENT: Two sealed cam follower bearings are used in the two positioner arms. To gain access to these, proceed as outlined under VALVE SHIFT SPRING and VALVE POSITIONER SPRINGS REPLACEMENT. The positioner housing can then be removed from the valve spool assembly. Remove the four 1/4-28 Allen nuts, then use a 3/8 diameter pin punch in the positioner spring holes to wedge the two halves of the positioner housing apart. In re-assembly, be sure that the round .010 brass spacers are placed (one) on each side of the positioner arms, and grease with marine water resistant grease every week.

PISTON ROD SEALS REPLACEMENT: All three rod seals are interchangeable.


NEW STYLE: Sealing is by means of a lip seal. The seal assembly may be removed by first removing the two-inch square retainer cap.

OLD STYLE: Sealing is by means of an outside surface o-ring, and inside seal, and a bronze bushing. The seal assembly may be removed by first removing the two-inch square retainer cap. The exposed end has a screwdriver groove which can be used for loosening. This end may then be grasped with pliers and rotated back and forth for removal. In assembly, be sure the screwdriver groove on the OD faces outward. (A Piston Rod Seal Kit including all parts listed above is available from Shamrock Automation)


PIVOT BEARINGS REPLACEMENT: All pivot bearings are sealed ball bearings. <u>Be sure</u> to replace a 1/4" flat washer (1/16" thick) on each side of every bearing to prevent binding.

DIE LUBE MIXER REPAIR KIT

		Mfg. Part#	Mfg. Part Name
MANIFOLD SEAL KIT		30100002	
Qty. 7 9 2 2	Ref. # DL68B DL67 DL68A EC001F	30100720 30100700 30100710 33090140	O-RING O-RING CUP SEAL O-RING
SPRING KIT		30100004	
<u>Qty.</u> 2 2	Ref.# DL16A DL25	30100300 30100220	SHIFT SPRINGS POSITIONER SPRINGS
WATER CYLINDER SEAL KIT		30100008	
Qty. 1 2 2 2 2	Ref.# DL60 DL92 DL64 DL62 XO11	30100640 30100780 30100670 30100660 33090240	O-RING O-RING PISTON ROD WIPER SEAL, ULTRATHANE O-RING
LUBE CYLINDER SEAL KIT		30100009	
Qty. 1 2 1 1	Ref.# DL58 DL91 DL64 DL62 XO11	30100620 30100770 30100670 30100660 33090240	O-RING O-RING PISTON ROD WIPER SEAL, ULTRATHANE O-RING



MFG PART NAME	BASE PLATE	SHIFT ACTUATING BRACKET	SHIFT ROD SPACED 16:1	SHIFT ROD SPACER 2:4 AND 3:4	SHIFT SPRING	SHIFT SPRING RETAINED 16:1	SHIFT SPRING RETAINER 2:1 AND 3:1	SHIFT ROD END CAP	ROCKER ARM	PIVOT BRACKET ASSEMBIV	OUTER ARM PIVOT	INNER ARM PINOT	HOSE ASSEMBLY
QUANTITY	1 EACH	1 EACH	1 EACH	1 EACH	2 EACH	2 EACH	2 EACH	1 EACH	1 EACH	1 EACH	1 EACH	1 EACH	1 EACH
MFG PART NO	30100025	30100260	30100380	30100390	30100300	30100310	30100320	30100330	30100340	30100365	30100400	30100410	30100455




Items 2, 12, and 13 are for Old Style Only

ASSEMBLY DRAWING VALVE ASSEMBLY WATER CYLINDER

O Items 2, 12, and 13 are for Old Style Only $\widehat{\boldsymbol{\omega}}$ 0 Ξ (M) O-RING PISTON ROD BUSHING (BRONZE) PISTON ROD BUSHING (GARLOCK) PISTON ROD WIPER RETAINER SCREW **(** € ROD SEAL CAGE RETAINER ROD SEAL CAGE OUTER WATER CYLINDER END CAP WATER CYLINDER TIE ROD PISTON SEAL WATER PISTON ASSEMBLY WATER CYLINDER BARREL 1/4"-28 GREASE FITTING ROD SEAL CAGE INNER SEAL ULTRATHANE 9 1/4"-28 ALLEN NUT MFG PART NAME 0 SEAL-CYLINDER (4)ന (E) QUANTITY 2 EACH 1 EACH 2 EACH 2 EACH 8 EACH 4 EACH 1 EACH 1 EACH EACH EACH EACH 9 MFG PART NO 30100070 30100080 30100660 30100050 30100030 30100029 30100029 32894230 32894230 30100650 30100650 30100650 (E)

Page 9



Page 10

VALVE CAGE ASSEMBLY FOR THE VARIABLE RATIO DIE LUBE MIXER


NOTE: Use only Shamrock Part No. 30100720 O-Rings on Valve Spool (7 required). These are available from Shamrock Automation. In an emergency, standard 01-010 O-Rings may be substituted.


TO REMOVE VALVE SPOOL ASSEMBLY FROM VALVE HOUSING: Refer to attached mixer drawing.

- (1) Remove valve shift rod cover.
- (2) Unbolt shifter bracket from water cylinder rod and rocker arm. Notice spacer washer under rocker arm bearing.
- Remove 2 valve positioner housing attachment bolts and carefully pull valve spool assembly from valve manifold. Caution: Valve spool can easily be damaged by bending.
- (4)* Insert a slightly undersized 3/8 diameter rod (such as a 3/8 ejector pin) into the valve cages, until it bottoms out against the inner valve cage rod seal. This prevents the valve cages from moving sideways during removal.
- (5)* Insert a 1/2" diameter rod from the opposite end of the valve manifold and gently tap out the spool assembly. This assembly is shown below.

*Do not perform these two steps unless replacing valve spool o-rings does not stop leakage.

NOTE: When re-installing valve cages, use the same 3/8 guide rod. **Use only Teflon grease on outer Orings.**





MFG PART NO	QUANTITY	MFG PART NAME
1 30100060 2 30100200 3 30100570 4 34210817 5 30100230 6 30100240 7 30100210 8 30100590 9 30100012 10 30100190 11 30100600 12 30100580 13 30100220	4 EACH 1 EACH 2 EACH 2 EACH 4 EACH 2 EACH 1 EACH 1 EACH 1 EACH 1 EACH 1 EACH 2 EACH	ALLEN NUTS 1/4"-28NF POSITIONER HOUSING (2 PIECE POSITIONER ARM PIVOT SHAFT 1/4" dia. X 1" ROLL PIN .01 THICK WASHER CAM ROLLER BEARING POSITIONER ARM POSITIONER BUSHING VALVE SPOOL ASSEMBLY VALVE CAGE END CAP ALIGNMENT RING POSITIONER SPRING RETAINER POSITIONER SPRING

WARRANTY

Seller fully warrants that equipment, service, repair or parts supplied shall conform to the description in the quotation and agrees to repair or replace F.O.B. shipping point, any parts (excepting expendable items such as ladle cups, ladle attachment brackets, ladle attachment arms, hydraulic seals, fuses, etc), services, or repairs that fail due to defects in material or workmanship within (1) one year of start-up of equipment or eighteen (18) months after shipment, whichever occurs first, or in the case of service, repairs, or part within one (1) year of supplying such service, repair, or part. If the equipment, service, repair, part includes software, Seller warrants, for a period of one (1) year of start-up or eighteen (18) months after shipment, whichever occurs first, that the software supplied or serviced will meet its published functional specifications. Should software fail to meet the specifications, or be otherwise defective, Seller shall promptly correct errors or non-conformities. If correction is not possible, Seller shall replace defective software, or, at Seller's option, refund the purchase price paid for such software. Other than those expressly state herein, THERE ARE NO OTHER WARRANTIES OF ANY KIND, EXPRESSED OR IMPLIED, AND SPECIFICALLY EXCLUDED, BUT NOT BY WAY OF LIMITATION, ARE THE IMPLIED WARRANTIES OF FITNESS FOR PARTICULAR PURPOSE AND MERCHANTABILITY.

IT IS UNDERSTOOD AND AGREED THAT SELLER'S LIABILITY, WHETHER IN CONTRACT, IN TORT, UNDER ANY WARRANTY, IN NEGLIGENCE OR OTHERWISE SHALL NOT EXCEED AND BUYER'S REMEDY IS LIMITED TO EITHER (I) REPAIR OR REPLACEMENT OF THE DEFECTIVE PARTS F.O.B. SHIPPING POINTS OR CORRECTION OF DEFECTIVE SERVICE OR REPAIR, OR AT SELLER'S OPTION (II) RETURN OF THE PRODUCT AND REFUND OF THE PURCHASE OF SERVICE PRICE. UNDER NO CIRCUMSTANCES SHALL SELLER BE LIABLE FOR SPECIAL, INDIRECT, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, THE PRICE STATED FOR THE EQUIPMENT, SERVICE, REPAIR OR PARTS IS A CONSIDERATION IN LIMITING SELLER'S LIABILITY. NO ACTION, REGARDLESS OF FORM, ARISING OUT OF THE TRANSACTIONS OF THIS AGREEMENT MAY BE BROUGHT BY PURCHASER MORE THAN ONE YEAR AFTER THE CAUSE OF ACTION HAS ACCRUED. THE WARRANTY FOR THE EQUIPMENT, SERVICE, REPAIR, OR PARTS PROPOSED IN THIS QUOTATION AS STATED IN THE ABOVE PARAGRAPHS. IT IS NOT RE-STATED-NOR DOES IT APPEAR IN ANY OTHER FORM.